

**OFTEC TECHNICAL BOOK THREE PART 1 (DOMESTIC)**  
**DOMESTIC OIL SUPPLY**

5b For extended fill pipework:

Pressurise the pipework hydraulically to 7 bar or 1.5 times working pressure, whichever is the greater, and leave standing for a minimum of 30 minutes.

5c For approved plastic underground oil supply lines:

Refer to the manufacturers' test instructions and procedures.

6 If during repair work joints are made in underground oil supply lines, permanent access to these must be provided.